


KEY NOTES

- 1 Remove all casework, equipment, utilities and finishes and prep for new construction
- 2 Remove wall and door.
- 3 Remove portion of wall for new high window opening. refer to structural for additional information.
- 4 Remove Plumbing fixtures
- 5 Remove steel stair
- 6 Remove dock leveler and infill recess space with concrete floor to match adjacent floor level.
- 7 Remove garage door and prep for new infill.
- 8 Remove exterior window and door. Prep for infill
- 9 Protect existing electrical equipment in place to accommodate new construction around equipment.
- 10 Remove door and prep for infill
- 11 Remove portion of wall for new room configuration
- 12 Structure above. refer to ceiling plan and electrical for work on the soffit
- 13 Protect existing gas meter

10 Existing / Deconstruction Plan
 A2.20 Scale 1/8"=1'-0"



REGISTERED ARCHITECT
 STATE OF WASHINGTON

LEEKA Architecture and Planning
 Creating Positive Impressions in the Built Environment
 503.844.4222 | lee@leeka.com | www.leeka.com

1001 SE Water Avenue Suite 175
 Portland, Oregon 97214

**Tenant Improvement
 ESD112
 Mental Health Facility Phase II**
 2400 NE 65th Ave. Vancouver, WA.

Revised:	
Job No:	2246
Date:	May 26, 2023
File Size:	24x36
Permit Application	
DRAWN:	NYL
CHECKED:	NYL
Sheet Title	Deconstruction Plan
Sheet Number	A2.20

COPYRIGHT - LEEKA INC. - ALL RIGHTS RESERVED